

29-2003

Virtalukon käyttöohje

Tändningslåsets användarmanual

Ignition switch user manual

Malli:

P-0-1-2-3

Ominaisuudet

- Hehku (diesel)
- Starttitoiminto
- Roiskevesisuoja
- Lattaliittimet (faston)
- Asennusreiän halkaisija: Ø 26,5 mm

Asento	Merkintä	Toiminto
Lepo	Lukittu	Kaikki virrat katkaistu, avain poistettavissa
P	Parkki	Parkkivalot / lisävarusteet (jos kytketty)
0	OFF	Virrat pois päältä
1	ON	Virta päällä (mittaristo, sähköt aktiivisia)
2	HEHKU	Hehkutus (dieselmoottori)
3	START	Starttimoottori käynnistyy (jousipalautteinen)

Modell:

P-0-1-2-3

Funktioner

- Glöd (diesel)
- Startfunktion
- Stänkskyddad
- Plana terminaler (faston)
- Monteringshålets diameter: Ø 26,5 mm

Placera	Märkning	Funktion
Vila	Låst	All ström bryts, nyckeln kan tas ut
P	Parkering	Parkeringsljus / extrautrustning (om inkopplad)
0	OFF	Strömmen av
1	ON	Ström på (instrument, el aktiva)
2	GLÖD	Glödning (dieselmotor)
3	START	Startmotor aktiveras (fjäderåtergående)

Model:

P-0-1-2-3

Features

- Glow (diesel)
- Start function
- Splash-proof
- Flat terminals (faston)
- Mounting hole diameter: Ø 26.5 mm

Position	Label	Function
Rest	Locked	All power off, key removable
P	Park	Parking lights / accessories (if connected)
0	OFF	Power off
1	ON	Power on (dashboard, electrics active)
2	GLOW	Preheating (diesel engine)
3	START	Starter motor engages (spring-return)